



# SILVER DIP G

## Silverware Detarnisher



### PROPERTIES

**Silver Dip G** has been designed to remove tarnish quickly, from all silverware.

### USE DIRECTIONS

1. Clean the soiled silverware before detarnishing.
2. Fill suitable container  $\frac{3}{4}$  full with **Silver Dip G**.  
Dip the tarnished silver item or items into the solution and allow to soak until the tarnish is removed. Approximately 6-10 seconds. Not exceed 30 seconds.  
**DO NOT ALLOW THE STAINLESS STEEL BLADE COME INTO CONTACT WITH SILVER DIP G**
3. Remove the detarnished items and rinse in clean water and allow to air dry or pass through a dishmachine in the regular manner.

**Do not use this product for stainless steel items.**



For emergency medical information call Ecolab: 001 1 651 222-5352

Consult your Ecolab Representative for specific use instructions and recommended dispensing equipment. For cautionary and first aid information, please refer to the Safety Data Sheet (SDS) or product label.