



# STONEMEDIC MPC MARBLE POLISHING COMPOUND

## Marble Polishing & Restoring Cream



### PROPERTIES

**Stonemedic MPC Marble Polishing Compound** is a ready mixed polishing paste for polish restoration of worn marble, travertine, limestone and agglomerates. Also provides initial water/stain resistance.

### USE DIRECTIONS

Ensure the surface to be polished is free from all coatings and soiling.

1. Select an area of approximately 40 sq ft for the polishing process.
2. Lightly wet the floor with clean water and place ¼ spoon of **Stonemedic MPC Marble Polishing Compound** in the center of the area to be worked.
3. Using a red pad work the product over the area with a 175 to 300 RPM floor machine. The consistency of the slurry should be fluid enough to achieve even coverage. If the slurry becomes too dry, add water as needed.
4. After making several side-to-side passes, squeegee back the slurry to determine that a consistent level of polish is achieved.



For emergency medical information call Ecolab: 001 1 651 222 5352

Consult your Ecolab Representative for specific use instructions and recommended dispensing equipment. For cautionary and first aid information, consult the Material Safety Data Sheet (MSDS) or product label.